

SENTRY ESD PROTECTION PRODUCTS

Wrist and Foot-strap Testers

Function

This range of products has been developed to test foot-straps, wrist-straps and cords.

There are three instrument types.

- Wrist-strap tester
- Single pass foot-strap tester (both feet)
- Single pass wrist-strap and foot-strap tester (both feet)

Description

The operator stands on the double foot-plate (when foot-strap testing) and connects the wrist strap cord (when wrist-strap testing). Testing is initiated by touching the touch pad.

High and low limit failures are indicated by red LEDs for left foot, right foot and wrist.

Pass is indicated by a green LED.

Specification

Limits (wrist):	From 0.75 M Ohms to 35 M Ohms
Limits (foot):	From 0.9 M Ohms to 100 M Ohms
Power supply:	9 volts battery
Indicators:	Battery low High limit fail Pass Low limit fail Left foot Right foot Audible alarm
Wall plate:	Optional

For more information www.sentry-esd.com



Available from:

Expodata Ltd
Canford Business Park
Magna Road
WIMBORNE
Dorset
BH21 3AP
ENGLAND
Tel: + 44 (0) 1202 593 777 Fax: + 44 (0) 1202 593 455
Email: enquiries@expodata.co.uk



Sentry – Always on guard